

BRIEF LIST OF REFERENCE NUMBERS
USED IN THE DRAWINGS

10	gear shaft assembly
11	hurricane shutter panel
12	lower channel assembly
13	upper channel assembly
14	lower housing channel
15	drive shaft
16	lower housing bottom wall
17	lower housing front wall
18	lower housing rear wall
19	first aperture in shaft support
20	shaft support
21	second aperture, in lower housing
22	third aperture, in lower housing
23a	first gear
23b	second gear
24	external bearing housing
25	central portion of external bearing housing
26	front arm of external bearing housing
27	rear arm of external bearing housing
28	fourth aperture in external bearing housing
29	journal bearing
30	threaded rod
31	screw boss
32	nut portion
33	fifth aperture

34	lock nut
35	internal bearing housing
36	lower channel rivet holes
37	internal bearing housing rivet holes
38	rivet
39	sixth aperture
40	T-nut
41	carrier arm
42	slot
43	arm aperture
44	T-nut aperture
45	arm rivet hole
46	support disk
47	first set screw
48	first lower housing wall hole
49	disk hole
50	first nut
51	orifice
52	upper channel
53	upper channel top wall
54	upper channel front wall
55	upper channel rear wall
56	upper channel set screw
57	upper channel wall hole
58	roller
59	second nut
60	roller aperture
61	false shutter

62	rebate
63	lower housing
64	tandem lower housing
65	housing pins
66	slip clutch
70	tandem gear shaft assembly
71	sliding attachment system
72	sliding bar
73	window sill bar
74	sliding attachment rollers
76	channel
77	stainless steel rivets